

Safe Operating Procedures

W77 Descaler

Suitable for use in kitchens and food preparation areas.

Task

Descaling

Chemical

W77 Descaler

Procedure

1. As a Bain Marie Cleaner - Dilute W77 1:5 with water. Tank may be heated to increase cleaning efficiency.
2. To descale dishwashing machine: Turn chemical dispenser off. Fill wash tank, add 500mL of W77. Run wash cycle 2 or 3 times. After wash cycle examine machine for areas of heavy build-ups and re run wash cycle a couple more times or use W77 neat with scourer to remove these heavy deposits. Then drain tank and refill with fresh water only. Run wash cycle to perform a rinse, then drain tank again. Turn chemical dispenser back on and refill dishwasher.

Note: It is very important that skin and eye contact do not occur.

Wear gloves & safety goggles. Avoid breathing vapours.



⚠ Precautions

- Wear chemical goggles.
- Wear a PVC apron if available.
- Maintain adequate ventilation when using.
- Use rubber elbow length gloves and apron.
- Always read SDS & labels before using chemical product.

☠ Hazards

- Will cause severe burns to the mouth, throat and stomach with effects including mucous build-up, irritation to the tongue and lips and pains in the stomach, which may lead to nausea, vomiting and diarrhea.
- Will cause severe burns to the eyes with effects including: tearing, pain, corneal opacity and blurred vision. Risk of serious damage to eyes.
- Will cause severe burns to the skin, with effects including; redness, itching and drying/defatting.
- Mists from the product will cause irritation to the nose, throat and respiratory system with effects including; coughing, discomfort, breathing difficulty and shortness of breath.
- Prolonged or repeated skin contact may lead to dermatitis.
- Prolonged eye contact may cause permanent eye damage.



P 1300 228 222
E we.care@veridia.com.au
W veridia.com.au